



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632
www.ridetech.com

Part # 11320500
78-88 GM "G" Body Front Black Series Shock Kit
For Use w/ CoolRide

Components:

2	20000011	Shock absorbers – eye stud
2	MON32245	Hardware Kit
2	90001619	Cantilver pin
2	90000471	Aluminum spacer
1	90000422	Driver side upper shock bracket
1	90000423	Passenger side upper shock bracket

Hardware:

6	99371004	3/8" x 1 1/4" USS bolt	Upper shock bracket to frame
6	99372002	3/8" Nylok nut	Upper shock bracket to frame
12	99373003	3/8" SAE flat washer	Upper shock bracket to frame

Installation Instructions



1. The shock bracket must be mounted first. It bolts right behind the upper arm and locates off the large hole in the frame and in the bracket. The brake line bracket must be removed and then reinstalled over the top of the shock bracket. The shock bracket is secured with 1 1/4" x 3/8" bolts with Nylok nuts and flat washers.

Note: There is a driver and passenger side bracket. The picture shows the drivers side.



2a. **If using the factory lower arm;** a .625" hole must be drilled in rear leg of the lower arm for the cantilever pin. This hole should be approximately 9" from the ball joint.

2b. **If using lower StrongArm;** the cantilever pin will attach directly to the tab welded to the rear leg of the control arm.

3. Push the cantilever pin through the bottom of the shock. Slide the washer over the pin, then the aluminum spacer. Fasten assembly to lower arm w/ nut supplied.