



350 S. St. Charles St. Jasper, In. 47546  
Ph. 812.482.2932 Fax 812.634.6632  
[www.ridetech.com](http://www.ridetech.com)

**Part # 11324499**  
**78-88 GM "G" Body Rear Lower StrongArms**

**Components:**

- |   |          |   |
|---|----------|---|
| 2 | 90001021 | Lower StrongArm – WW 19.25"                                       |
| 8 | 90001089 | Poly bushing half – .75" I.D. x 1.5" O.D. x 1.125" long           |
| 4 | 90000516 | Bushing sleeve - .5" I.D. x .75" O.D. x 2.375" long               |
| 2 | 90001092 | Tube of Lithium grease – to lubrication bushing mounting surfaces |



# STRONG ARMS™

by Air Ride Technologies

## Installation Instructions



1. Remove the sway bar (if equipped) and factory lower trailing arm. Do one side at a time to keep the axle from rotating.
2. Clean bushing mounting surfaces on frame. Lubricate w/ lithium grease supplied.
2. Attach to front on the lower StrongArm to the frame using factory hardware.
3. This arm has holes in the tube for sway bar attachment. Mount the bar so that the holes are closest to the axle.



4. Attach to rear of the lower StrongArm to the frame using the factory hardware.
- Note:** These polyurethane bushing are lubricated at the factory w/ lithium grease.
- Note:** Tighten the bolts enough to remove any lateral movement and apply moderate drag on bushings. Over-tightening can cause excessive suspension bind.