



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632
www.ridetech.com

Part # 11393699
82-03 S-10 Upper StrongArms

Components:

1	90000429	Drivers side arm
1	90000430	Passenger side arm
2	90000899	Upper ball joint
2	90000436	Cross shaft
4	90001599	Inner bushing sleeve
4	90001090	Poly bushing half

Hardware:

4	99563001	9/16" USS flat washer	Installed between bushing and shaft
4	99603003	5/8" USS flat washer	Installed between nut and bushing
4	99622005	5/8" SAE crimp locking nuts	Cross shaft to bushing

STRONG ARMS™

by Air Ride Technologies



1. Fasten the upper arm to the frame using the factory hardware. Reinstall the current alignment shims, but **vehicle must be realigned.**

2. Drop ball joint down through upper arm. Slide ball joint boot over stud, then place boot retainer over the boot. Clamp assembly tight w/ the hardware supplied.

3. Fasten the ball joint to the spindle w/ the new castle nut and cotter pin supplied.

4. Tighten the cross shaft nuts enough to create drag on the poly bushings, the arm should still move.

ridete
Air Ride Technologies

UCA5000 S-10 UPPER CONTROL ARM

PASSENGER SIDE

