



## 99-15 F-250/350 CURVED 54" LIGHT BRACKETS

Thank you for choosing Rough Country for all your suspension needs.

Please read instructions before beginning installation. Check the kit hardware against the kit contents shown below. Be sure you have all needed parts and know where they go.

This bracket kit was designed to fit a Led curved light 53.625" long from mounting surface to mounting surface.

### KIT CONTENTS

Driver Bracket (1)  
Passenger Bracket (1)  
3/16" Rivets (7)

### TOOLS NEEDED

3/16" Drill Bit  
Pop Rivet Gun  
Tape Measure

### INSTALLATION INSTRUCTIONS

1. Open the passenger door and remove the weather stripping. Measure 22.250" from the bottom of the seal flange up the windshield post to the top edge of the light bracket. Mark the position of the light bracket. **See Photo 1.**
2. Next hold the light bracket in position and drill the three holes through the sheet metal with a 3/16" drill bit as shown in **Photo 2.** **\*Note\*** May want to place a piece of tape on the drill bit 1/2" from the end for a depth gage. Drilling to far will damage the outside painted surface of the A-pillar.



PHOTO 1



PHOTO 2

3. Use the supplied 3/16" rivets to secure the light brackets. **See Photo 3.** Repeat steps on the driver side.
4. Install the Led Light with the supplied instructions. **See Photo 4.**



PHOTO 3



PHOTO 4

5. With the door shut it may be required to trim the weather stripping so it sits flat on the new brackets.

By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable Federal, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.