

350 S. St. Charles St. Jasper, In. 47546 Ph. 812.482.2932 Fax 812.634.6632 www.ridetech.com

Part # 11239100 64-67 GM "A" Body Front MuscleBar

Components:

	1	
1	90000156	Front sway bar (37.875")
1	90000148	Driver side arm
1	90000149	Passenger side arm
2	90000152	Frame plate
2	90000150	Frame bracket
2	90000926	90 degree 10mm PosiLink
2	90000924	Straight 10mm PosiLink
4	90000717	T-bushing (PosiLink to lower arm)
2	90001099	Polyurethane frame bushing - 1.5" I.D.
2	1/4" - 28 straight grease zerk	
1	90001092	Tube of Lithium grease


Hardware:

ı	30000143	r assenger side ann			
2	90000152	Frame plate			
2	90000150	Frame bracket			
2	90000926	90 degree 10mm PosiLink	. 05		
2	90000924	Straight 10mm PosiLink	- Clie		
4	90000717	T-bushing (PosiLink to lower arm)	2109		
2	90001099	Polyurethane frame bushing - 1.5" I.D.	W.C.		
2	90000150 Frame bracket 90000926 90 degree 10mm PosiLink 90000924 Straight 10mm PosiLink 90000717 T-bushing (PosiLink to lower arm) 90001099 Polyurethane frame bushing - 1.5" I.D. 1/4" - 28 straight grease zerk 90001092 Tube of Lithium grease				
1	90001092	Tube of Lithium grease	76		
			:de		
Hardware:					
2	99371028	3/8" x 3/4" USS Flat head Allen bolt	Frame plate to frame		
4	99371004	3/8" x 1 1/4" USS bolt	Frame bracket		
14	99373003	3/8" SAE flat washer	Frame bracket / Sway bar arm to bar		
10	99373005	3/8" lock washer	Frame bracket / Sway bar arm to bar		
6	99371017	3/8" x 1" Button head Allen bolt	Sway bar arm to bar		
4	99112002	10mm Nylok nut	PosiLink		
2	99115001	10mm x 1.5 x 36mm stud (use Loctite)	PosiLink		
2	99502003	½" SAE Nyloc jam nut	Steering arm		



Installation Instructions

- 1. This sway bar was designed for use with our lower StrongArms. Installation with other control arms may require modification.
- 2. Remove the end links from the factory sway bar. Then remove the bolts attaching the sway bar to the frame.



- 3. Bolt the frame plate to the frame using the factory sway bar holes. The front hole will use a 3/8" x 3/4" flat head Allen screw. The rear hole will use a standard 3/8" x 1 1/4" hex bolt.
- 4. Using the bracket as a guide, drill the front hole with a 5/16" bit and thread with a 3/8"-16 tap.

Note: On some cars the factory bolt holes may be 5/16" and will need to be drilled and tapped to accept a 3/8" bolt.



- 5. Slide the poly bushing over the bar and lubricate with the lithium grease supplied.
- 6. Slide the bracket over the bushing and fasten the bar to the frame using 3/8" x 1 1/4" bolts, flat washers and lock washers.

Note: Future lubrication should only be done with non-petroleum based lubricants.



- 7. Bolt the sway bar arm to the bar using 3/8" x 1" Button head screws with flat washers and lock washers.
- 8. Fasten the 90 degree end of the PosiLink to the sway bar arm using a 3/8" flat washer on each side of the arm and a 10mm Nylok nut.
- 9. Two T-bushing will be used on each side to attach the straight end of the PosLink to the lower control arm. Secure with a 10mm Nylok nut.
- 10. Install the thin ½" Nylok nuts on the front bolt of the steering arm, and cut off excess threads.
- 11. Check PosiLink alignment through full suspension travel to ensure that it does not bind.

