



350 S. St. Charles St. Jasper, In. 47546
Ph. 812.482.2932 Fax 812.634.6632
www.ridetech.com

Part # 11334099
63-72 Chevy C-10 Rear CoolRide Kit
For Use w/ Factory Trailing Arms

Components:

2	90006781	Rear air spring – 267c
2	90000056	Upper air spring cup bracket
2	90000070	Lower air spring plate
2	90001082	Short bump stop

Hardware Kit:

4	99372002	3/8" USS Nylok nut	Air spring to upper mount
4	99373003	3/8" SAE washer	Air spring to upper mount
2	99435003	7/16" x 2" stud	Upper mount to frame
2	99432001	7/16" Nylok nut	Upper mount to frame
2	99433002	7/16" SAE washer	Upper mount to frame
2	99371009	3/8" x 4" bolt	Air spring to trailing arm
2	99373001	3/8" fender washer	Air spring to trailing arm
2	99373005	3/8" lock washer	Air spring to trailing arm

COOLRiDE[®]

by Air Ride Technologies

Installation Instructions

1. Raise the vehicle to a safe and comfortable working height with the suspension hanging freely.
2. Remove the coil spring and shock absorbers.



3. Apply thread sealant to a 90 degree air fitting and screw it into the top of the air spring.

Note: When using larger fittings you may need to trim the bracket and/or frame rail.

4. Place the upper mount over the studs on the air spring. Secure with two 3/8" Nylok nuts and flat washers.

5. Screw the 7/16 x 2" stud into the nut in the bottom of the bracket.

7. Bolt the assembly to the upper coil spring pocket with the stud sticking through the frame. Use a 7/16" nut and flat washer to fasten the assembly.

8. Bolt the bottom of the air spring to the trailing arm using a 3/8" x 4" bolt, fender washer and lock washer. The lower air spring plate must be installed between the air spring and the trailing arm.

9. Double check air spring clearance though full suspension travel.

10. Ride height on this air spring is approximately 5".

DO NOT ALLOW THE AIR SPRING TO RUB. THIS WILL DAMAGE THE AIR SPRING AND IS NOT A WARRANTABLE SITUATION.